

# OPEN FIRST!!

## Parts list for Master set # 16.18103 92-95 HONDA CIVIC / CRX 93-97 HONDA DEL SOL including VTEC



1131 VIA CALLEJON, SAN CLEMENTE, CA 92673

© 2015 Energy Suspension. All rights reserved.  
May not be reproduced, in any form, or by any means,  
without the written consent of Energy Suspension.

It is recommended that if you are unfamiliar with this type of work that you refer to a qualified service center specializing in this type of work. It is also recommended that if you choose to do this work yourself that a factory service manual be obtained for the proper procedures pertaining to removal, replacement and proper torque specifications for your vehicle. This instruction set is intended as a guideline for the safe installation of Energy Suspension's polyurethane bushings, once you have removed the factory components from your vehicle. Wheel alignment is almost always disturbed when suspension components are removed or replaced. It is recommended that you have the alignment checked on your vehicle at a qualified alignment shop. Energy Suspension recommends that you read over all the installation instructions and check all P/N's and quantities in the parts list before you start. Call customer service at 949-361-3935 if the parts in your kit do not match this parts list. Prior to installation, make sure that your car is in excellent mechanical condition and that there are no suspension or steering related problems. This part has been designed to work only with a car that is in good state of repair. No matter how carefully we design our parts, this is one area we have no control over and cannot be held responsible.

### Parts list:

Energy Suspension recommends that you **read over all the installation instructions** and check all P/N's and quantities in the parts list **before you start**. Call customer service at 949-361-3935 if the parts in your kit do not match this parts list.

#### Transmission shifter stabilizer bushing set: 16.1102

- 1 - 1033 (mounts near shifter)
- 2 - 2277 (mounts at the transmission)
- 1 - 15.10.247.39 (.500"O.D. x .312" I.D. x 1.200" sleeve)
- 1 - 17161 installation instructions

#### Front end control arm bushing set: 16.3105

- 2 - 3285 lower control arm pivot bushing(rear position)
- 2 - 15.10.246.39 (1.00"O.D. x .718" I.D. x 2.277" sleeve)
- 4 - 2274 lower control arm pivot bushing(front position)
- 2 - 15.10.245.39 (.750"O.D. x .480" I.D. x 1.960" sleeve)
- 4 - 3284 upper control arm pivot bushing
- 4 - 15.10.244.39 (.750"O.D. x .406" I.D. x 1.577" sleeve)
- 1 - 17141 installation instructions

#### Rear end control arm bushing set: 16.3104

- 8 - 2269 lower control arm pivot bushing
- 4 - 3283 lower control arm pivot bushing
- 4 - 15.10.279.39 (.750"O.D. x .406" I.D. x 1.960" sleeve)
- 1 - 17140 installation instructions

#### Front shock bushing set(press out bushing and shell): 16.8102

- 4 - 2272 lower control arm shock mount
- 4 - 8096 upper shock mount(use O.E. sleeve)
- 2 - 15.10.245.39 (.750"O.D. x .480" I.D. x 1.960" sleeve)
- 1 - 17162 installation instruction

#### Rear shock bushing set(press out bushing and shell): 16.8103

- 4 - 2270 lower control arm shock mount
- 4 - 8096 upper shock mount(use O.E. sleeve)
- 2 - 15.10.279.39 (.750"O.D. x .406" I.D. x 1.960" sleeve)
- 1 - 17163 installation instruction

Please refer to our newest catalog for more information on custom applications including bump stops, shock bushings, universal mounts, tie rod boots, ball joint boots, transmission mounts, Formula 5 Prelube etc. Please ask to see our catalog at your place of purchase.

### Parts list continued:

#### Front endlink set: 16.8104

- 8 - 8072 endlink bushing
- 2 - 15.10.226.39 (.562" O.D. x .375" I.D. x .400" sleeve)
- 8 - 15.03.03.40 cupped washer
- 2 - 15.05.28.39 (3/8"-16 x 3-3/4" bolt)
- 2 - 15.07.01.40 (3/8"-16 nylock nut)
- 1 - 17236 installation instructions

#### Rack and pinion bushing set: 16.10102

- 4 - 10022 drivers side (all models)
- 1 - 10024 passenger side (power steering only. Bushing not available for other models)
- 1 - 17153 installation instructions

#### Front balljoint boot set: 16.13101

- 2 - 13001 (lower balljoint)
- 2 - 13003 (upper balljoint)

#### Tie rod boot set: 9.13103

- 2 - 13003 tie rod boots

#### 93-97 DEL SOL (VTEC ONLY)

- 1 - 1032(mounts at the transmission)

### Additional parts available for your vehicle:

Rear Trailing Arm bushing set: 16.7106

#### Front anti-swaybar bushing set (does not include endlinks):

Bar Dia.	Set #
24mm	16-5104
22mm	16-5108
21mm	16-5105

#### Rear anti-swaybar bushing set (does not include endlinks):

Bar Dia.	Set #
15mm	16-5117
13mm	16-5107

17159 ECN 15132 18/DEC/15 MAX