

# OPEN FIRST!!

## Parts list for Master set # 16.18108 1990-93 Honda Accord

# ENERGY SUSPENSION®

1131 VIA CALLEJON, SAN CLEMENTE, CA 92673

© 2004 Energy Suspension. All rights reserved.  
May not be reproduced, in any form, or by any means,  
without the written consent of Energy Suspension.

It is recommended that if you are unfamiliar with this type of work that you refer to a qualified service center specializing in this type of work. It is also recommended that if you choose to do this work yourself that a factory service manual be obtained for the proper procedures pertaining to removal, replacement and proper torque specifications for your vehicle. This instruction set is intended as a guideline for the safe installation of Energy Suspension's polyurethane bushings, once you have removed the factory components from your vehicle.

### Parts list:

Energy Suspension recommends that you **read over all the installation instructions** and check all P/N's and quantities in the parts list **before you start**. Call customer service at 949-361-3935 if the parts in your kit do not match this parts list.

#### Front end control arm bushing set:16.3110

- 4 - 2306 lower control arm bushing outer.
- 2 - 3289 lower control arm bushing center.
- 2 - 15.10.302.39 lower control arm sleeve.  
(3/4"O.D. x 12mm I.D. x 2.040")
- 8 - 2280 upper control arm bushing.
- 4 - 15.10.244.39 upper control arm sleeve.  
(3/4"O.D. x 10mm I.D. x 1.577")
- 1 - 17152 installation instructions.

#### Front strut rod set:16.7103

- 2 - 7096 rear position.
- 2 - 7097 front position.

#### Front shock bushing set:16.8106

- 4 - 8096 upper shock bushing.
- 4 - 2295 lower shock bushing.
- 2 - 15.10.302.39 lower shock sleeve.  
(3/4"O.D. x 12mm I.D. x 2.040")
- 1 - 17162 installation instructions.

#### Front end link set:16.8105

- 8 - 8098 end link bushing.
- 2 - 15.10.200.39 sleeve.  
(1/2"O.D. x 3/8" I.D. x .400")
- 2 - 15.05.28.39 (3/8" - 16 x 3-3/4") bolt.
- 2 - 15.07.01.40 (3/8" - 16) locknut.
- 8 - 15.03.29.39 (1-1/2"O.D. x 3/8" I.D.) cup washer.

## 17293

18/JUN/99 BRH  
Updated 23/JAN/04 BRH

### Parts list continued:

#### Front balljoint boot set:16.13102 upper & lower

- 2 - 13003 balljoint boot.
- 2 - 13005 balljoint boot.

#### Front tie-rod boot set:9.13103

- 2 - 13003 tie-rod boot.

#### Front spring pad set:16.6101

- 2 - 6133 upper spring pad.

**Grease:** 1 - 9.11101 grease tubs.

### Additional parts available for your vehicle:

#### Front anti-swaybar bushing set (does not include endlinks):

Bar Dia. 25mm Set # 9.5129

#### Rear anti-swaybar bushing set (does not include endlinks):

Bar Dia. 14mm Set # 16.5116

#### Motor mount insert set: set# 16.1107 (manual trans only)

Rear balljoint boot set: set# 16.13103

Please refer to our newest catalog for more information on custom applications including bump stops, shock bushings, universal mounts, tie rod boots, ball joint boots, transmission mounts, Formula 5 Prelube etc. Please ask to see our catalog at your place of purchase.

# B.O.M. For Master set # 16.18108

Updated 23/JAN/04  
18/JUN/99 BRH  
16-18108.cdr

## Parts list:

### Front end control arm bushing set:16.3106

4 - 2306  
2 - 3289  
2 - 15.10.302.39 (3/4"O.D. x 12mm I.D. x 2.040")  
8 - 2280  
4 - 15.10.244.39 (3/4"O.D. x 10mm I.D. x 1.577")  
1 - 17152 installation instructions.

### Front strut rod set:16.7103

2 - 7096  
2 - 7097

### Front shock bushing set:16.8106

4 - 8096  
4 - 2295  
2 - 15.10.302.39 (3/4"O.D. x 12mm I.D. x 2.040")  
1 - 17162 installation instructions.

### Front end link set:16.8105

8 - 8098  
2 - 15.10.200.39 (1/2"O.D. x 3/8" I.D. x .400")  
2 - 15.05.28.39 (3/8" - 16 x 3-3/4" bolt).  
2 - 15.07.01.40 (3/8" - 16 locknut).  
8 - 15.03.29.39 (1-1/2"O.D. x 3/8" I.D. cup washer).

## Parts list continued:

### Front balljoint boot set:16.13102

2 - 13003  
2 - 13005

### Front tie-rod boot set:9.13103

2 - 13003

### Front spring pad set:16.6101

2 - 6133

### Grease:

1 - 9.11101

### Parts list"

1 - 17293

## Packaging Instructions

  
All sleeves and instructions for  
each set must be packaged  
together in individual bags.

Fold the parts list # 17293 so the

**"OPEN FIRST!!**

On the Master set 16.18108"  
Is clearly visible when packaged  
on skin packing card.