

OPEN FIRST!!

Parts list for

Master set # 3.18110

78-88 Chevelle, Monte Carlo, El Camino

Parts list:

Energy Suspension recommends that you **read over all the installation instructions** and check all P/N's and quantities in the parts list **before you start**. Call customer service at 949-361-3935 if the parts in your kit do not match this parts list.

Transmission mount set:: 3.1108

- 1 - 1036 mount
- 1 - 15.08.10.39 backing plate
- 2 - 15.03.48.39 (7/16" lockwasher)
- 4 - 15.03.42.39 (7/16" flat washer)
- 2 - 15.05.30.39 (7/16"-14 x 1" bolt)
- 1 - 17112 installation instructions

Front control arm bushing set: 3.3156

- 2 - 15.02.02.39 ("B" shell)
- 2 - 3008 bushing (lower rear position)
- 2 - 15.10.10.39 sleeve (.750"O.D. x .500" I.D. x 2.400")
- 2 - 15.02.11.39 ("K" shell)
- 2 - 3217 bushing (lower front position)
- 2 - 15.10.45.39 sleeve (.750" O.D. x .500" I.D. x 3.000")
- 4 - 15.02.16.39 ("P" shell)
- 4 - 3083 bushing (upper control arm)
- 4 - 15.10.44.39 sleeve (.875"O.D. x .688" I.D. x 1.900")
- 1 - 17019 installation instructions

Rear control arm bushing set: 3.3132

- 8 - 15.02.09.39 ("I" shell)
- 8 - 3021 bushing
- 8 - 15.10.10.39 sleeve (.750"O.D. x .500" I.D. x 2.425")
- 6 - 3087 thrust washer
- 6 - 3088 thrust washer
- 2 - 3089 thrust washer
- 1 - 17019 installation instructions
- 1 - 17041 installation instructions

Rear coil spring isolator set: 3.6108

- 2 - 6138 isolator

Front Swaybar endlink set: 9.8119

- 8 - 4806 endlink grommets
- 2 - 15.10.24.39 sleeve (.563"O.D. x .375" I.D. x 3.375")
- 8 - 15.03.01.39 (cupped washer)
- 2 - 15.05.05.39 (3/8"-16 x 7-1/2" bolt)
- 2 - 15.07.01.40 (3/8"-16 nut)



1131 VIA CALLEJON, SAN CLEMENTE, CA 92673

© 2011 Energy Suspension. All rights reserved.
May not be reproduced, in any form, or by any means,
without the written consent of Energy Suspension.

It is recommended that if you are unfamiliar with this type of work that you refer to a qualified service center specializing in this type of work. It is also recommended that if you choose to do this work yourself that a factory service manual be obtained for the proper procedures pertaining to removal, replacement and proper torque specifications for your vehicle. This instruction set is intended as a guideline for the safe installation of Energy Suspension's polyurethane bushings, once you have removed the factory components from your vehicle.

Parts list continued:

Tie-rod boot set: 9.13101

- 4 - 13001 tie-rod boots

Ball-joint boot set: 9.13126

- 2 - 13009
- 2 - 13010

Additional parts available for your vehicle:

UNIVERSAL/MULTI. APPLICATION SWAY BAR BUSHINGS

Greasable	Diameter	Non-greasable
Set #		Set #
9.5151	7/16"	9.5101
9.5152	1/2"	9.5102
9.5153	9/16"	9.5103
9.5154	5/8" (16mm) --	9.5104
9.5155	11/16"	9.5105
9.5156	3/4" (19mm) --	9.5106
9.5157	13/16"	9.5107
9.5158	7/8" (22mm) --	9.5108
9.5159	23mm	9.5115
9.5160	15/16" (24mm)	9.5109
9.5161	1"	9.5110
9.5162	1 1/16"	9.5111
9.5163	28mm	9.5130
9.5164	1 1/8"	9.5112
9.5165	1 1/4"	9.5113
9.5166	32mm	9.5116
9.5167	1 5/16"	9.5114
9.5168	1 3/8"	9.5136

1978-88 Front Upper Bump Stop SET # 3.9102
1978-85 Front Lower Bump Stop SET # 3.9150

BODY MOUNT SET FOR

1978-88 MONTE CARLO SET # 3.4141

Please refer to our newest catalog for more information on custom applications including bump stops, shock bushings, universal mounts, tie rod boots, ball joint boots, transmission mounts, Formula 5 Prelube etc. Please ask to see our catalog at your place of purchase.

17179

10/3/2013 KLB