

OPEN FIRST!! ENERGY SUSPENSION®

1131 VIA CALLEJON, SAN CLEMENTE, CA 92673

Parts List for Master set # 5-18108

© 2005 Energy Suspension. All rights reserved.
May not be reproduced, in any form, or by any means,
without the written consent of Energy Suspension.

Parts list:

Energy Suspension recommends that you
read over all the installation instructions
and parts list **before you start.**

Front control arm bushing set: 5.3129

- 4 2406 Lower CAB horizontal bushings
- 2 15.10.409.39 Sleeve (.812x.562x2.272)
- 2 3406 Lower CAB "top" bushings
- 2 3407 Lower CAB "middle" bushings
- 2 3408 Lower CAB "lower" bushings
- 1 17344 Installation instructions
- 2 9.11108 Grease tubes

Front sway bar bushing set: 5.5153

- 2 5316 24mm front sway bar bushings
- 1 17145 Instruction sheet
- 1 9.11108 Grease tube

Front endlinks: 5.8105

- 8 8072 Bushings
- 2 15.10.92.39 Sleeves (.563x.375x.800)
- 8 15.03.03.39 Washers
- 2 15.05.28.39 Bolts (3/8-16x3-3/4")
- 2 15.07.01.39 Nuts (3/8-16 Nylon Lock Nut)

Rear trailing arm bushing set: 5.7113

- 2 7111 Trailing arm bushings
- 2 15.10.530.39 Sleeve (1.000 x .500 x 2.56)
- 2 9.11108 Grease tubes

Rear spring pad set: 5.6110

- 4 6197 Spring Pads

Rear sway bar bushing set: 5.5152

- 2 5601 16mm rear sway bar bushings
- 4 8272 Endlink bushings
- 1 17145 Instruction sheet
- 1 9.11108 Grease tube

Rear Bump Stop set: 5.6107

- 2 6198 Bump stops

Rear Watts Link: 5.8106

- 4 3154 Bushings
- 2 15.10.102.39 Sleeves (.750x.500x1.600)
- 1 9.11108 Grease tube

Front lower tranny torque arm inserts set: 5.1105

- 1 1145 Torque insert "Driver side"
- 1 1146 Torque insert "Passenger side"
- 2 15.08.77.01 Nylon square tie
- 2 15.08.79.01 Button
- 1 17347 Installation instructions

