



Thank you for being selective enough to choose a Dinan Performance Intake System. The Dinan Engineering Team has spent many hours developing this product to assure that you will receive increased performance, durability and an aesthetic design that you as a customer will be able to enjoy for many years. Ease of installation and maintenance is important to us and has been highly considered throughout the design process.

Prior to performing the installation, familiarize yourself with these instructions as it should help you with the process. If you feel that you do not have the required skills or tools, please arrange for a qualified repair facility to perform the installation.

If you have any difficulties during the installation, or if these instructions are not clear to you, please call Dinan's Technical Support Staff at (800) 341-5480.

Again, thank you for choosing Dinan. Enjoy.

## Installation Instructions

### D180-0013: Strut Brace

Document Revision: A  
Release Date: Jan 19, 2022

#### Vehicle Applications:

2021 + G22/23 M440i / 430i and xDrive  
2022 + G26 M440i / 430i and xDrive

### Table of Contents

Parts List.....	2
Removal of Stock Braces.....	2
Installation of Dinan Braces.....	2

## Parts List

- (1) D182-0069- Strut Brace, Left
- (1) D182-0070- Strut Brace, Right

## Removal of Stock Braces

1. Loosen screws.
2. Remove the strut braces (4 locations). The screws will be re-used.

## Installation of Dinan Braces

1. Position the left and right brace. The 'DINAN' logo shall read left to right when viewing from its respected side of the vehicle.
2. Tighten the screws.
  - a. Tightening torque = 56 Nm (41 ft-lb)