

# *aFe Control Front Tow Hooks 2022 Toyota Tundra*

**Product Number:** 450-72T001-R

**Install Time:** 10 Min. (Front Tow Hooks),



| Full Kit Contents | Front & Rear Sway Bar Set | Qty. |
|-------------------|---------------------------|------|
| 00P-0P2627-R      | S/A Tow Hook, Tundra      | 2    |

**Recommended Tools:**

- Socket: 17mm
- Socket Wrench
- Torque Wrench

**Installation:**

1. Park the vehicle, we suggest installing the tow hooks with the weight of the vehicle on its tires.
2. Put the Active Aero Front Spoiler into the service position by keying the vehicle off and then raising and holding the wiper stalk in the upward position for about two seconds.
3. Support the sway bar in position.
4. Using the 17mm socket, remove the bolts connecting the left side sway bar bushing bracket to the chassis. Retain the bolts for installation.
5. Remove the lower sway bar bracket and replace with the aFe Control tow hook.
6. Re-use the bolts removed in the previous step. It is recommended to start these bolts by hand, they are fine pitch and easy to cross thread.
7. Torque the two bolts to 51 ft-lbs (70 Nm)
8. Repeat the same procedure on the right side of the vehicle.
9. Start the vehicle and put into drive to raise the Active Aero Front Spoiler.

