



advanced FLOW engineering

Instruction Manual P/N: 52-10003C/52-10003CS

Rapid Induction Cold Air Intake System Cover

Ford Edge ST 2019-2020 V6-2.7L(tt)



Qty.	Part Description
1	Rapid Induction Cover

- Please read the entire instruction manual before proceeding.
- Ensure all components listed are present.
- If you are missing any of the components, call customer support at 951-493-7100.
- Ensure you have all necessary tools before proceeding.
- Ensure that your vehicle is cooled off before proceeding.
- Retain factory parts for future use.

1. Remove the trim seal from your aFe POWER Cold Air Intake System.
2. Install your new cover, ensuring the locking tabs are on the inside of the sheet metal housing and the longer edges sit on the outside.

NOTE: Check all screws, clamps, and connectors are secure after 100-200 miles