



## INSTALLATION INSTRUCTIONS

### Pre-Cut Black UnderHood Thermal Acoustic Lining

50124	'70 - '72 Chevelle (non-fucntional cowl)
50125	'68 - '69 Chevelle
50126	'67 Chevelle
50127	'66 Chevelle
50128	'64-'65 Chevelle
50099	'67 -'69 Camaro - Z28, SS, Base
50098	'69 -'70 Mustang - Base, Mach 1, Grande, GT-350, GT
50097	'70 -'72 Chevelle - Base
50096	'69 -'74 Nova
50096	'71 -'74 Ventura - Base, GTO
50096	'73 -'74 Omega
50096	'73 -'74 Apollo
50095	'68 -'70 LeMans / GTO
50094	'65 -'67 LeMans / GTO
50093	'66 -'67 Nova
50084	'84 - '01 Jeep XJ

#### NOTES:

The cleaner the area the stronger the bond will be. Use a wax and grease remover and/or isopropyl alcohol.

#### SURFACE PREP:

Vacuum installation area to remove all loose debris. Then clean with isopropyl alcohol, soapy water, or a wax/grease remover. Allow sufficient time to dry before installation of Boom Mat products.



Photo for illustration purposes only. Each model differs.

#### INSTRUCTIONS:

1. Each kit is pre-cut for your specific vehicle. Take pieces and test fit them into the proper areas so you can put the correct piece in the proper place.
2. Clean surface area with a wax and grease remover or isopropyl alcohol to make sure it is as clean as possible.
3. Remove the backing to expose the adhesive and carefully apply to clean and dry desired area.
4. After Under Hood is set in proper location, apply pressure to ensure a strong bond with installation surface.