



INSTALLATION INSTRUCTIONS

Boom Mat Under Carpet

KIT CONTENTS:

- #50100 - 24" x 54" (9 sq. ft.) Under Carpet
- #50101 - 48" x 54" (18 sq. ft.) Under Carpet
- #50102 - BULK 1 Linear ft. x 54"W Under Carpet

NOTES:

Our Hi Temp Adhesive (10492) can be used to secure in place if necessary.

TOOLS:

Boom Mat blade lock knife (050216) or snips

SURFACE PREP:

Vacuum installation area to remove all loose debris. Then clean with isopropyl alcohol, soapy water, or a wax/grease remover. Allow sufficient time to dry before installation of Boom Mat products.

INSTRUCTIONS:

1. Making a template will aid in proper and professional installations.
2. Trim Boom Mat Under Carpet to desired size using a knife.
3. After Boom Mat Under Carpet is set in proper location, you may apply spray adhesive to both the Boom Mat Under Carpet material and the surface it is being installed on to secure in place if desired.

