



INSTALLATION INSTRUCTIONS

Thank you for purchasing genuine Design Engineering, Inc. products. Be sure to always wear the proper safety equipment when installing any DEI product. Design Engineering Inc. WILL NOT BE HELD LIABLE FOR IMPROPER INSTALLATION OR USE OF THIS PRODUCT. Please follow all instructions provided. If you are unsure of any installation procedure, please contact a certified technician.

DESCRIPTION: Under Carpet Lite
50110 - 24" x 70" Under Carpet Lite
50111 - 48" x 70" Under Carpet Lite
50112 - Bulk 1 Linear foot x 70" Under Carpet Lite
50113 - 6ft x 70" Under Carpet Lite

NOTES:
Our Hi-Temp Adhesive Spray (10492) or Adhesive Transfer Tape (50205 - 1 roll or 50207 - 2 rolls) can be used to secure in place if necessary.

UC Lite is installed with gray side up (dark side up)

SURFACE PREP:
Vacuum installation area to remove loose debris. Then clean with isopropyl alcohol, soapy water or wax/grease remover. Allow sufficient time to dry before installation of Boom Mat products

NOTE OF CAUTION: Wear eye and hand protection when installing all materials. Use spray adhesive in a well ventilated area.

INSTRUCTIONS:

1. Making a template will aid in proper and professional installations.
2. Trim Boom Mat Under Carpet Lite to desired size using scissors or knife.
3. After Boom Mat Under Carpet Lite is set in proper location, you may apply spray adhesive (DEI Part 50490) to both the Under Carpet Lite material and the surface it is being installed on to secure in place if desired. Or use Adhesive Transfer Tape (50205 - 1 roll or 50207 - 2 rolls)



UC Lite trimmed & being applied with spray adhesive



UC Lite installed with gray side up