



INSTALLATION INSTRUCTIONS

Thank you for purchasing genuine Design Engineering, Inc. products. Be sure to always wear the proper safety equipment when installing any DEI product. Design Engineering Inc. WILL NOT BE HELD LIABLE FOR IMPROPER INSTALLATION OR USE OF THIS PRODUCT. Please follow all instructions provided. If you are unsure of any installation procedure, please contact a certified technician.

DESCRIPTION: Leather Look Sound Barrier

KIT CONTENTS:

50120 - 24" x 48" (8 sq. ft.) Leather Look
50121 - 48" x 48" (16 sq. ft.) Leather Look
50122 - BULK 1 Linear ft. x 48"W Leather Look

TOOLS NEEDED:

Boom Mat blade lock knife (50216) or snips

SAFETY:

Safety glasses
Gloves

NOTE OF CAUTION: Wear eye and hand protection when installing all materials. Use spray adhesive in a well ventilated area.

OVERVIEW: Leather Look Sound Barrier blocks noise from trunks, floors, firewalls and more with a finished leather embossed pattern.



STEP 1. Making a template will aid in proper and professional installations.

STEP 2. Trim Boom Mat Leather Look Sound Barrier to desired size using scissors.

STEP 3. After Boom Mat Leather Look Sound Barrier is set in proper location, you may apply DEI Hi-Temp Spray Adhesive (DEI part # 10492) to both the Boom Mat Leather Look material and the surface it is being installed on to secure in place if desired.