



INSTALLATION INSTRUCTIONS

Thank you for purchasing genuine Design Engineering, Inc. products. Be sure to always wear the proper safety equipment when installing any DEI product. Design Engineering Inc. WILL NOT BE HELD LIABLE FOR IMPROPER INSTALLATION OR USE OF THIS PRODUCT. Please follow all instructions provided. If you are unsure of any installation procedure, please contact a certified technician.

DESCRIPTION: D-Mat Insulation

KIT CONTENTS:

- 50410 D-Mat 60" x 40"
- 50411 D-Mat 60" x 70"
- 50412 D-Mat 60" wide x linear foot
- Instructions

TOOLS NEEDED:

- Heavy duty scissors
- Adhesive spray or mechanical fasteners

SAFETY:

- Safety glasses
- Gloves

NOTE OF CAUTION: Wear eye and hand protection when installing all materials. Use spray adhesive in a well ventilated area.

OVERVIEW: D-Mat is an excellent all round thermal and acoustic insulator. It can be used in most automotive applications but we do not recommend it for under carpet. Uses include, under the headliner, firewall, doors and trunks. D-Mat is also great in RV applications for insulation and sound control.



Fig 1

STEP 1. D-Mat cuts easily with scissors or utility knife.

STEP 2. Measure the area you wish to cover and transfer this directly to the D-Mat or make a paper pattern. **Fig 1**

STEP 3. We recommend installing with the facing material facing out.



Fig 2

STEP 4. Once cut, test fit into the area before using DEI spray adhesive (10492). **Fig 2**



Fig 3

STEP 5. Once the fit is tested, spray a coating of DEI spray adhesive to the surface you are installing the D-Mat then press into place. **Fig 3**



Fig 4

STEP 6. D-Mat can also be installed with mechanical fasteners like staples or screws. It can also be just pushed into cavities. **Fig 4**