

Installation Instructions

For set # 3.1153
2010 Camaro Diff Bushings

ENERGY
SUSPENSION 

1131 VIA CALLEJON, SAN CLEMENTE, CA 92673

© 2008 Energy Suspension. All rights reserved.
May not be reproduced, in any form, or by any means,
without the written consent of Energy Suspension.

It is recommended that if you are unfamiliar with this type of work that you refer to a qualified service center specializing in this type of work. It is also recommended that if you choose to do this work yourself that a factory service manual be obtained for the proper procedures pertaining to removal, replacement and proper torque specifications for your vehicle. This instruction set is intended as a guideline for the safe installation of Energy Suspension's polyurethane bushings, once you have removed the factory components from your vehicle.


Parts list:

- 6 - 1271 Diff Bushing
- 3 - 15.10.472.39 Rear Position Sleeve
- 1 - 17551 Instruction Sheet

1. With the diff out and on the table, you need to pry up the flange on the stock bushing so your tooling will have something to grab on to. (See Picture)



2. You will need to press the old bushings out. Using one of these process (See Picture Below)



3. Then press in the new bushings and the sleeve. (See Picture)



TORQUE SPECS.
For set # 3.1153
2010 Camaro Diff Bushings

17551

17/DEC/09 BO