

# Instruction Sheet # 17151 3/AUG/10 BRH



1131 VIA CALLEJON, SAN CLEMENTE, CA 92673

© 2009 Energy Suspension. All rights reserved.  
May not be reproduced, in any form, or by any means,  
without the written consent of Energy Suspension.

## Instructions for correct positions and installation.

Clean and remove any rust or scale from the sway bar.  
Grease I.D. of bushing with supplied grease.  
Install bushings and brackets.

Set# 3.5175 1-1/16" dia. Use part # 5062 at control arm position.  
Set# 3.5176 1-1/8" dia. Use part # 5067 at control arm position.  
Set# 3.5177 1-1/4" dia. Use part # 5061 at control arm position.

It is recommended that if you are unfamiliar with this type of work that you refer to a qualified service center specializing in this type of work. It is also recommended that if you choose to do this work yourself that a factory service manual be obtained for the proper procedures pertaining to removal, replacement and proper torque specifications for your vehicle. This instruction set is intended as a guideline for the safe installation of Energy Suspension's polyurethane bushings, once you have removed the factory components from your vehicle.

# Instruction Sheet # 17151 3/AUG/10 BRH



1131 VIA CALLEJON, SAN CLEMENTE, CA 92673

© 2009 Energy Suspension. All rights reserved.  
May not be reproduced, in any form, or by any means,  
without the written consent of Energy Suspension.

## Instructions for correct positions and installation.

Clean and remove any rust or scale from the sway bar.  
Grease I.D. of bushing with supplied grease.  
Install bushings and brackets.

Set# 3.5175 1-1/16" dia. Use part # 5062 at control arm position.  
Set# 3.5176 1-1/8" dia. Use part # 5067 at control arm position.  
Set# 3.5177 1-1/4" dia. Use part # 5061 at control arm position.

It is recommended that if you are unfamiliar with this type of work that you refer to a qualified service center specializing in this type of work. It is also recommended that if you choose to do this work yourself that a factory service manual be obtained for the proper procedures pertaining to removal, replacement and proper torque specifications for your vehicle. This instruction set is intended as a guideline for the safe installation of Energy Suspension's polyurethane bushings, once you have removed the factory components from your vehicle.

# Instruction Sheet # 17151 3/AUG/10 BRH



1131 VIA CALLEJON, SAN CLEMENTE, CA 92673

© 2009 Energy Suspension. All rights reserved.  
May not be reproduced, in any form, or by any means,  
without the written consent of Energy Suspension.

## Instructions for correct positions and installation.

Clean and remove any rust or scale from the sway bar.  
Grease I.D. of bushing with supplied grease.  
Install bushings and brackets.

Set# 3.5175 1-1/16" dia. Use part # 5062 at control arm position.  
Set# 3.5176 1-1/8" dia. Use part # 5067 at control arm position.  
Set# 3.5177 1-1/4" dia. Use part # 5061 at control arm position.

It is recommended that if you are unfamiliar with this type of work that you refer to a qualified service center specializing in this type of work. It is also recommended that if you choose to do this work yourself that a factory service manual be obtained for the proper procedures pertaining to removal, replacement and proper torque specifications for your vehicle. This instruction set is intended as a guideline for the safe installation of Energy Suspension's polyurethane bushings, once you have removed the factory components from your vehicle.

# Instruction Sheet # 17151 3/AUG/10 BRH



1131 VIA CALLEJON, SAN CLEMENTE, CA 92673

© 2009 Energy Suspension. All rights reserved.  
May not be reproduced, in any form, or by any means,  
without the written consent of Energy Suspension.

## Instructions for correct positions and installation.

Clean and remove any rust or scale from the sway bar.  
Grease I.D. of bushing with supplied grease.  
Install bushings and brackets.

Set# 3.5175 1-1/16" dia. Use part # 5062 at control arm position.  
Set# 3.5176 1-1/8" dia. Use part # 5067 at control arm position.  
Set# 3.5177 1-1/4" dia. Use part # 5061 at control arm position.

It is recommended that if you are unfamiliar with this type of work that you refer to a qualified service center specializing in this type of work. It is also recommended that if you choose to do this work yourself that a factory service manual be obtained for the proper procedures pertaining to removal, replacement and proper torque specifications for your vehicle. This instruction set is intended as a guideline for the safe installation of Energy Suspension's polyurethane bushings, once you have removed the factory components from your vehicle.