

Instruction Sheet # 17151 3/AUG/10 BRH



1131 VIA CALLEJON, SAN CLEMENTE, CA 92673

© 2009 Energy Suspension. All rights reserved.
May not be reproduced, in any form, or by any means,
without the written consent of Energy Suspension.

Instructions for correct positions and installation.

Clean and remove any rust or scale from the sway bar.
Grease I.D. of bushing with supplied grease.
Install bushings and brackets.

Set# 3.5175 1-1/16" dia. Use part # 5062 at control arm position.
Set# 3.5176 1-1/8" dia. Use part # 5067 at control arm position.
Set# 3.5177 1-1/4" dia. Use part # 5061 at control arm position.

It is recommended that if you are unfamiliar with this type of work that you refer to a qualified service center specializing in this type of work. It is also recommended that if you choose to do this work yourself that a factory service manual be obtained for the proper procedures pertaining to removal, replacement and proper torque specifications for your vehicle. This instruction set is intended as a guideline for the safe installation of Energy Suspension's polyurethane bushings, once you have removed the factory components from your vehicle.

Instruction Sheet # 17151 3/AUG/10 BRH



1131 VIA CALLEJON, SAN CLEMENTE, CA 92673

© 2009 Energy Suspension. All rights reserved.
May not be reproduced, in any form, or by any means,
without the written consent of Energy Suspension.

Instructions for correct positions and installation.

Clean and remove any rust or scale from the sway bar.
Grease I.D. of bushing with supplied grease.
Install bushings and brackets.

Set# 3.5175 1-1/16" dia. Use part # 5062 at control arm position.
Set# 3.5176 1-1/8" dia. Use part # 5067 at control arm position.
Set# 3.5177 1-1/4" dia. Use part # 5061 at control arm position.

It is recommended that if you are unfamiliar with this type of work that you refer to a qualified service center specializing in this type of work. It is also recommended that if you choose to do this work yourself that a factory service manual be obtained for the proper procedures pertaining to removal, replacement and proper torque specifications for your vehicle. This instruction set is intended as a guideline for the safe installation of Energy Suspension's polyurethane bushings, once you have removed the factory components from your vehicle.

Instruction Sheet # 17151 3/AUG/10 BRH



1131 VIA CALLEJON, SAN CLEMENTE, CA 92673

© 2009 Energy Suspension. All rights reserved.
May not be reproduced, in any form, or by any means,
without the written consent of Energy Suspension.

Instructions for correct positions and installation.

Clean and remove any rust or scale from the sway bar.
Grease I.D. of bushing with supplied grease.
Install bushings and brackets.

Set# 3.5175 1-1/16" dia. Use part # 5062 at control arm position.
Set# 3.5176 1-1/8" dia. Use part # 5067 at control arm position.
Set# 3.5177 1-1/4" dia. Use part # 5061 at control arm position.

It is recommended that if you are unfamiliar with this type of work that you refer to a qualified service center specializing in this type of work. It is also recommended that if you choose to do this work yourself that a factory service manual be obtained for the proper procedures pertaining to removal, replacement and proper torque specifications for your vehicle. This instruction set is intended as a guideline for the safe installation of Energy Suspension's polyurethane bushings, once you have removed the factory components from your vehicle.

Instruction Sheet # 17151 3/AUG/10 BRH



1131 VIA CALLEJON, SAN CLEMENTE, CA 92673

© 2009 Energy Suspension. All rights reserved.
May not be reproduced, in any form, or by any means,
without the written consent of Energy Suspension.

Instructions for correct positions and installation.

Clean and remove any rust or scale from the sway bar.
Grease I.D. of bushing with supplied grease.
Install bushings and brackets.

Set# 3.5175 1-1/16" dia. Use part # 5062 at control arm position.
Set# 3.5176 1-1/8" dia. Use part # 5067 at control arm position.
Set# 3.5177 1-1/4" dia. Use part # 5061 at control arm position.

It is recommended that if you are unfamiliar with this type of work that you refer to a qualified service center specializing in this type of work. It is also recommended that if you choose to do this work yourself that a factory service manual be obtained for the proper procedures pertaining to removal, replacement and proper torque specifications for your vehicle. This instruction set is intended as a guideline for the safe installation of Energy Suspension's polyurethane bushings, once you have removed the factory components from your vehicle.