

INSTRUCTIONS FOR FORD REAR DROP LINK INSTALLATION

ENERGY
SUSPENSION 
Performance **POLYURETHANE** Components
1131 VIA CALLEJON, SAN CLEMENTE, CA 92673

The original lower drop link is bonded to a stud.

This stud must be reused.

1. After drop links are removed from the vehicle and the bushings are pressed out of the drop link eyes, apply heat to the flared end of the stud to loosen the bond.

2. Be sure and remove all old rubber from the stud.

No sleeve is required at this position.

© 2007 Energy Suspension. All rights reserved. May not be reproduced in any form or by any means without written consent of Energy Suspension.

17059

6/6/07 aen

INSTRUCTIONS FOR FORD REAR DROP LINK INSTALLATION

ENERGY
SUSPENSION 
Performance **POLYURETHANE** Components
1131 VIA CALLEJON, SAN CLEMENTE, CA 92673

The original lower drop link is bonded to a stud.

This stud must be reused.

1. After drop links are removed from the vehicle and the bushings are pressed out of the drop link eyes, apply heat to the flared end of the stud to loosen the bond.

2. Be sure and remove all old rubber from the stud.

No sleeve is required at this position.

© 2007 Energy Suspension. All rights reserved. May not be reproduced in any form or by any means without written consent of Energy Suspension.

17059

6/6/07 aen