

Installation instructions

For set # 4.8101
E-Series Endlink Bushings



1131 VIA CALLEJON, SAN CLEMENTE, CA 92673

© 2009 Energy Suspension. All rights reserved.
May not be reproduced, in any form, or by any means,
without the written consent of Energy Suspension.

It is recommended that if you are unfamiliar with this type of work that you refer to a qualified service center specializing in this type of work. It is also recommended that if you choose to do this work yourself that a factory service manual be obtained for the proper procedures pertaining to removal, replacement and proper torque specifications for your vehicle. This instruction set is intended as a guideline for the safe installation of Energy Suspension's polyurethane bushings, once you have removed the factory components from your vehicle.

- 1) Remove sway bar and O.E.M. shell from I-Beam.
- 2) De-burr sharp edges from both sides of axle.
- 3) To help installation, grease leading edge of bushing then install bushing into axle using a C-clamp and 2 wood blocks or metal washers.
- 4) Grease I.D. of bushing and O.D. of sway bar.
- 5) Reinstall sway bar.

17128

24/AUG/10 BRH

Installation instructions

For set # 4.8101
E-Series Endlink Bushings



1131 VIA CALLEJON, SAN CLEMENTE, CA 92673

© 2009 Energy Suspension. All rights reserved.
May not be reproduced, in any form, or by any means,
without the written consent of Energy Suspension.

It is recommended that if you are unfamiliar with this type of work that you refer to a qualified service center specializing in this type of work. It is also recommended that if you choose to do this work yourself that a factory service manual be obtained for the proper procedures pertaining to removal, replacement and proper torque specifications for your vehicle. This instruction set is intended as a guideline for the safe installation of Energy Suspension's polyurethane bushings, once you have removed the factory components from your vehicle.

- 1) Remove sway bar and O.E.M. shell from I-Beam.
- 2) De-burr sharp edges from both sides of axle.
- 3) To help installation, grease leading edge of bushing then install bushing into axle using a C-clamp and 2 wood blocks or metal washers.
- 4) Grease I.D. of bushing and O.D. of sway bar.
- 5) Reinstall sway bar.

17128

24/AUG/10 BRH

Installation instructions

For set # 4.8101
E-Series Endlink Bushings



1131 VIA CALLEJON, SAN CLEMENTE, CA 92673

© 2009 Energy Suspension. All rights reserved.
May not be reproduced, in any form, or by any means,
without the written consent of Energy Suspension.

It is recommended that if you are unfamiliar with this type of work that you refer to a qualified service center specializing in this type of work. It is also recommended that if you choose to do this work yourself that a factory service manual be obtained for the proper procedures pertaining to removal, replacement and proper torque specifications for your vehicle. This instruction set is intended as a guideline for the safe installation of Energy Suspension's polyurethane bushings, once you have removed the factory components from your vehicle.

- 1) Remove sway bar and O.E.M. shell from I-Beam.
- 2) De-burr sharp edges from both sides of axle.
- 3) To help installation, grease leading edge of bushing then install bushing into axle using a C-clamp and 2 wood blocks or metal washers.
- 4) Grease I.D. of bushing and O.D. of sway bar.
- 5) Reinstall sway bar.

17128

24/AUG/10 BRH