



1131 VIA CALLEJON, SAN CLEMENTE, CA 92673

© 1998 Energy Suspension. All rights reserved.
May not be reproduced, in any form, or by any means,
without the the written consent of Energy Suspension.

17271
J3/15/99
Instructions for set # 5-1102 (Note; Customer must **reuse** original **hardware** and **factory sleeve**). Remove center console to access shifter mounting plate. Remove factory rubber bushings and discard, save inner metal sleeve and hardware as it will need to be reused. Install factory metal sleeve into polyurethane bushing #1101 and install onto shifter plate from the top. Install polyurethane bushing ring #1102 onto protruding nipple of bushing #1101 under shifter plate. Install all remaining bushings and hardware and tighten all fasteners.



1131 VIA CALLEJON, SAN CLEMENTE, CA 92673

© 1998 Energy Suspension. All rights reserved.
May not be reproduced, in any form, or by any means,
without the the written consent of Energy Suspension.

17271
J3/15/99
Instructions for set # 5-1102 (Note; Customer must **reuse** original **hardware** and **factory sleeve**). Remove center console to access shifter mounting plate. Remove factory rubber bushings and discard, save inner metal sleeve and hardware as it will need to be reused. Install factory metal sleeve into polyurethane bushing #1101 and install onto shifter plate from the top. Install polyurethane bushing ring #1102 onto protruding nipple of bushing #1101 under shifter plate. Install all remaining bushings and hardware and tighten all fasteners.



1131 VIA CALLEJON, SAN CLEMENTE, CA 92673

© 1998 Energy Suspension. All rights reserved.
May not be reproduced, in any form, or by any means,
without the the written consent of Energy Suspension.

17271
J3/15/99
Instructions for set # 5-1102 (Note; Customer must **reuse** original **hardware** and **factory sleeve**). Remove center console to access shifter mounting plate. Remove factory rubber bushings and discard, save inner metal sleeve and hardware as it will need to be reused. Install factory metal sleeve into polyurethane bushing #1101 and install onto shifter plate from the top. Install polyurethane bushing ring #1102 onto protruding nipple of bushing #1101 under shifter plate. Install all remaining bushings and hardware and tighten all fasteners.



1131 VIA CALLEJON, SAN CLEMENTE, CA 92673

© 1998 Energy Suspension. All rights reserved.
May not be reproduced, in any form, or by any means,
without the the written consent of Energy Suspension.

17271
J3/15/99
Instructions for set # 5-1102 (Note; Customer must **reuse** original **hardware** and **factory sleeve**). Remove center console to access shifter mounting plate. Remove factory rubber bushings and discard, save inner metal sleeve and hardware as it will need to be reused. Install factory metal sleeve into polyurethane bushing #1101 and install onto shifter plate from the top. Install polyurethane bushing ring #1102 onto protruding nipple of bushing #1101 under shifter plate. Install all remaining bushings and hardware and tighten all fasteners.