

# Installation Instructions

## Nissan Maxima Front Sway Bar Set



1131 VIA CALLEJON, SAN CLEMENTE, CA 92673

It is recommended that if you are unfamiliar with this type of work that you refer to a qualified service center specializing in this type of work. It is also recommended that if you choose to do this work yourself that a factory service manual be obtained for the proper procedures pertaining to removal, replacement and proper torque specifications for your vehicle. This instruction set is intended as a guideline for the safe installation of Energy Suspension's polyurethane bushings, once you have removed the factory components from your vehicle.

Support the car on jack stands, you will need to remove the wheels to gain access to the sway bar clamp. When loosening the bolts, turn the steering wheel all the way to the left or right, depending on the side you are working on. (Pic 1) This will give you more room to work with as the steering boot is compressed and out of the way. Now remove the clamp and remove the OEM bushing. (Pic 2) Now grease the I.D. of the new Energy bushing and reinstall. Tighten the clamp bolts to factory specifications. (Pic 3)



Pic 1



Pic 3



Pic 2

© 2005 Energy Suspension. All rights reserved.  
May not be reproduced, in any form, or by any means,  
without the written consent of Energy Suspension.

Must reuse OEM  
bracket and bolts.  
Pic 2.



031605NT

17445

# Installation Instructions

## Nissan Maxima Front Sway Bar Set



1131 VIA CALLEJON, SAN CLEMENTE, CA 92673

It is recommended that if you are unfamiliar with this type of work that you refer to a qualified service center specializing in this type of work. It is also recommended that if you choose to do this work yourself that a factory service manual be obtained for the proper procedures pertaining to removal, replacement and proper torque specifications for your vehicle. This instruction set is intended as a guideline for the safe installation of Energy Suspension's polyurethane bushings, once you have removed the factory components from your vehicle.

Support the car on jack stands, you will need to remove the wheels to gain access to the sway bar clamp. When loosening the bolts, turn the steering wheel all the way to the left or right, depending on the side you are working on. (Pic 1) This will give you more room to work with as the steering boot is compressed and out of the way. Now remove the clamp and remove the OEM bushing. (Pic 2) Now grease the I.D. of the new Energy bushing and reinstall. Tighten the clamp bolts to factory specifications. (Pic 3)



Pic 1



Pic 3



Pic 2

© 2005 Energy Suspension. All rights reserved.  
May not be reproduced, in any form, or by any means,  
without the written consent of Energy Suspension.

Must reuse OEM  
bracket and bolts.  
Pic 2.



031605NT

17445