

AEROMOTIVE Part # 15141 INSTALLATION INSTRUCTIONS

This product is not legal for sale or use on emission-controlled vehicles except when used as a direct replacement part matching OEM specification.

WARNING!



Always be aware of flammable situations. Drilling and grinding can be potential ignition sources. Extinguish all open flames, prohibit smoking and eliminate all sources of ignition in the area of the vehicle and workspace before proceeding with the installation. Ensure you are working in a well ventilated area with an approved fire extinguisher nearby.

WARNING!



Installation of this product requires modification to a fuel tank/ the fuel system, failure to satisfy all safety considerations will result in fire, explosion, injury and/or loss of life to yourself and/or others. All fuel system components MUST be located as far from heat sources as possible, like exhaust, engine block,

etc.

WARNING!



Mechanical and hydraulic lifting devices can tip over or lower accidentally due to incorrect maneuvering or technical errors. A falling object can cause injury and/or loss of life to yourself and/or others. When working under the vehicle, always use stands, and ensure that the ground or floor is stable and level. Never crawl under a vehicle which is only supported by a jack.

WARNING!



The fuel system is under pressure. Do not open the fuel system until the pressure has been relieved. Refer to the appropriate vehicle service manual for the procedure and precautions for relieving the fuel system pressure.

CAUTION!



When installing this product always wear safety glasses and other appropriate safety apparel. A drilling operation will cause flying metal chips. Flying metal chips can cause eye injury.

CAUTION:



Installation of this product requires detailed knowledge of automotive systems and repair procedures. We recommend that this installation be carried out by a qualified automotive technician. Careless installation of this product can result in damage to the product, injury or loss of life to yourself and/or others.

Compatible Fuels:

Pump Gas Race Gas E85 Alcohol/Ethanol

Parts Included:

1ea 15141 assembly
1ea 15141 mounting bracket (use with 13577429 only)
2ea 10-24 machine screws
2ea #10 lock washer

The included fuel sensor adapter has all necessary O-rings for sealing the adapter to the sensor. This adapter is made to work with the following flex fuel sensor part numbers: 13577429, 13577379, 13577394. There is a modification that needs to be done to part number 13577394, see below for further details.



13577394 needs to be trimmed to 3.75" so 1.875" from the center of the sensor.



The following steps are typical of most installations:

- 1. Once the engine has been allowed to cool, disconnect the negative battery cable and relieve fuel system pressure, referring to the appropriate vehicle service manual for the procedure on doing so.
- 2. Locate a suitable location to attach the fuel sensor using the provided bracket or the sensor itself depending on the part number of the sensor. (Install per sensor installation instructions)
- 3. Now that the sensor has a place to be installed, install the sensor into the sensor adapter to ensure the location will work for the area needed for the entire assembly.
- 4. To assemble the sensor adapter, follow the steps below.
 - a. Disassembly the sensor adapter.
 - b. Ensure all O-rings are in place, two should be in the sensor holes in each side and one larger O-ring in the face O-ring groove. (Lubricate the O-rings prior to reassembly)
 - c. Slide one side of the adapter on the sensor then follow suit with the other side.
 - d. Install the 2 ¾ 10-32 screw with lock washed into the adapter and tighten.
 - e. Next depending on the sensor install the bracket and 10-24 screws into the back side of the assembled adapter.
- 5. Install the sensor and sensor adapter into the vehicle and plumb per fuel system requirements.
- 6. Reconnect the battery, pressurize the fuel system and check for leaks from and around all fuel system components and all fuel lines and connections. If any fuel leaks are found, turn ignition to the OFF position, remove spilled fuel and repair leak(s).

Contact US

RGA NUMBER REQUIRED FOR ALL RETURNS TO AEROMOTIVE. To obtain an RGA number, please call (913) 647–7300 and ask for the Returns and Repairs department.

Shipping Address
 Aeromotive Inc.
 10955 Mill Creek Road
 Lenexa, KS 66219

General Inquiries and Tech Line: (913) 647-7300

General Email: info@aeromotiveinc.com
Tech Email: tech@aeromotiveinc.com

The Aeromotive Tech Lines are open Monday through Friday from 9:30AM to 5:00PM Central Standard Time.



WARNING: This product can expose you to chemicals, including chromium, which is known to the State of California to cause cancer or birth defects or other reproductive harm. For more information, visit: www.p65Warnings.ca.gov

AEROMOTIVE, INC. LIMITED WARRANTY

This Aeromotive Product, with proof of purchase dated on or after January 1, 2003, is warranted to be free from defects in materials and workmanship for a period of one year from the original date of purchase. No warranty claim will be valid without authentic, dated proof of purchase.

This warranty is to the original retail purchaser and none other and is available directly from Aeromotive and not through any point of distribution or purchase.

If a defect is suspected, the retail purchaser must contact Aeromotive directly to discuss the problem, possible solutions and obtain a Return Goods Authorization (RGA), if deemed necessary by the company. Please call 913-647-7300 and dial option 3 for the technical service dept. All returns must be shipped freight pre-paid to the company and with valid RGA before they will be processed.

Aeromotive will examine any product returned with the proper authorization to determine if the failure resulted from a defect or from abuse, improper installation, misapplication or alteration. Aeromotive will then, at it's sole discretion, return, repair or replace the product.

If any Aeromotive product is determined defective, buyer's exclusive remedy is limited in value to the sale price of the good. In no event shall Aeromotive be liable for incidental or consequential damages.

Aeromotive expressly retains the right to make changes and improvements in any product it manufactures and sells at any time. These changes and improvements may be made without notice at any time and without any obligation to change the catalogs or printed materials.

Aeromotive expressly retains the right to discontinue at any time and without notice any Aeromotive product that it manufactures or sells.

This warranty is limited and expressly limits any implied warranty to one year from the date of the original retail purchase on all Aeromotive products.

No person, party or corporate entity other than Aeromotive shall have the right to: determine whether or not this Limited Warranty is applicable to any Aeromotive product, authorize any action whatsoever under the terms and conditions of this Limited Warranty, assume any obligation or liability of any nature whatsoever on behalf of Aeromotive under the terms and conditions of this Limited Warranty.

This Limited Warranty covers only the product itself and not the cost of installation or removal.

This Limited Warranty is in lieu of and expressly excludes any and all other warranties, expressed or implied. This Limited Warranty gives you specific legal rights, and you may also have other rights which vary from state to state.