



## advanced FLOW engineering

Dynamic Air Scoop D.A.S.

**Instruction Manual** P/N: 54-10468/-L/-R/-N/-GN/-GR

---

Make: BMW Model: 3-Series/M3 (E46) Year: 1999-2007 Engine: L6



- Please read the entire instruction manual before proceeding.
- Ensure all components listed are present.
- If you are missing any of the components, call customer support at 951-493-7185.
- Ensure you have all necessary tools before proceeding.
- Do not attempt to work on your vehicle when the engine is hot.
- Disconnect the negative battery terminal before proceeding.
- Retain factory parts for future use.

Label	Qty.	Description	Part Number
A	1	Scoop	05-01045 (Black)
			05-01045L (Blue)
			05-01045R (Red)
			05-01045GN (Green)
			05-01045N (Orange)
			05-01045GR (Gray)

Warranty Information available at: <https://afepower.com/contact#warranty>

**Emission Disclaimer:**

This product is not currently CARB exempt and is not available for purchase in California or for use on any vehicle registered with the state of California Department of Motor Vehicles.





FigureA

Refer to Figure A for step 1

Step 1: Remove plastic pins on ram air duct. (Save for later installation)

REMOVAL



FigureB

Refer to Figure B for step 2

Step 2: Remove air inlet duct and OE screws.



Figure C

Refer to [Figure C](#) for step 3

Step 3: Insert DAS. Position scoop hole on plastic tab support



Figure D

Refer to Figure D for step 4

Step 4: Install DAS by using OE screws.



**Figure E**

Refer to Figure E for step 5

Step 5: Re-install air duct using plastic pins removed in step 1. Installation is now complete.

Thank you for choosing aFe Power!



Page left blank intentionally







**advanced FLOW engineering, inc.**  
252 Granite Street Corona, CA 92879  
<https://afepower.com/contact>