

PRODUCT INSTRUCTIONS

Thank you for purchasing genuine Design Engineering, Inc. products. Be sure to always wear the proper safety equipment when installing any DEI product. Design Engineering Inc. WILL NOT BE HELD LIABLE FOR IMPROPER INSTALLATION OR USE OF THIS PRODUCT. Please follow all instructions provided. If you are unsure of any installation procedure, please contact a certified Powersports technician.

DESCRIPTION: Exhaust Sleeve Titanium 2"

PART NUMBER: 901155

APPLICATION(s): Universal

KIT CONTENTS:

Exhaust Sleeve Titanium 2"x5'	QTY 1
Stainless Tie 9mm	QTY 1
Stainless Tie 12mm	QTY 1
Tie Tool	QTY 1

TOOLS NEEDED: 1/4" driver, side cutters, and scissors

OVERVIEW: A great looking alternative to traditional wrap, this sleeve kit will keep you cool and give you a clean, classy look.




Fig. 1



Fig. 2

1. Remove exhaust from bike.
2. Clean exhaust thoroughly
3. Fold the loose ends of the sleeve inward and slide onto the exhaust pipe. Compress the sleeve (like an accordion) to expand the diameter. This makes it easier to slide onto the exhaust. Fig. 1
4. Secure one end of the sleeve with supplied stainless tie. Fig. 2
5. Pull the end of the sleeve, tightening around the exhaust. Work any extra slack from the sleeve.
6. Make a mark on the sleeve at end of the exhaust, leaving a little extra that can be tucked in.
7. Cut the sleeve using a sharp pair of shears.
8. Fold the loose ends in and secure with supplied stainless tie.
9. Break-in: It is common for the exhaust sleeve to smoke for a few heat cycles, this is normal.



INS-2018 Rev. 1-20-17

For additional installation tips and videos visit: deipowersports.com

Design Engineering, Inc.
604 Moore Rd Avon Lake, Ohio 44012
800-264-9472 deipowersports.com