



INSTALLATION INSTRUCTIONS

Thank you for purchasing genuine Design Engineering, Inc. products. Be sure to always wear the proper safety equipment when installing any DEI product. Design Engineering Inc. WILL NOT BE HELD LIABLE FOR IMPROPER INSTALLATION OR USE OF THIS PRODUCT. Please follow all instructions provided. If you are unsure of any installation procedure, please contact a certified technician.

DESCRIPTION: Floor & Tunnel Shield II

KIT CONTENTS:

- #50501 2 ft x 21" (3.5 sq ft)
- #50502 4 ft x 21" (7.0 sq ft)
- #50503 4 ft x 42" (14.0 sq ft)
- #50509 4 ft x 42" (14.0 sq ft)
- #95503 10" X 10" (.83 sq ft)
- Instructions

TOOLS NEEDED:

Scissors or snips, Cardboard/Poster board to use as a template, marker

SAFETY:

Safety glasses
Gloves

NOTE OF CAUTION: Wear eye and hand protection when installing all materials. Use spray adhesive in a well ventilated area.

OVERVIEW: Floor & Tunnel Shield II is an extreme heat barrier that blocks heat from the engine, exhaust and road from components, interiors, electrical, wire, hoses & more.



Fig 1

STEP 1. Although Floor & Tunnel Shield II will stick to almost anything, we recommend removing dirt, grease, oil, wax, etc. to improve adhesion.

STEP 2. Making a template will aid proper and professional installations. **Fig 1**



Fig 2

STEP 3. Trim Floor & Tunnel Shield II to desired size using a snips or scissors.

STEP 4. Remove the backing to expose the adhesive and carefully apply to clean and dry desired area. **Fig 2**



Fig 3

STEP 5. After Floor & Tunnel Shield II is set in proper location, apply pressure to ensure a strong bond with the installation surface. **Fig 3**